

Solimar® Print Director™ Enterprise (SPDE)




XRocks Printer Controller Utility Module

Overview

The XRocks Printer Controller module drives and controls printing with special commands for Xerox LPS Metacode printers.

The XRocks Printer Controller module generates user defined DJDE and RSTACK commands and downloads resources to the printer's hard drive. DJDE commands are used to control Xerox printer features such as duplex, start command, and feed drawer selection. This module can modify existing DJDEs in the data or generate new DJDE commands to modify how the job is processed by Xerox LPS printers or SPDE XCHANGE:: modules.



Technical Specifications

- Inserts user definable RSTACK records before or after data for report separation
- Generates any DJDE command to modify print data on-the-fly, such as: COPIES=, JDE=, JDL=, FORM=, DUPLEX=, OTEXT=, DEPT, etc.
- Provides a user definable IDEN preamble
- Generates ASCII and EBCDIC DJDE commands
- Enables downloading resources including fonts, forms, logos, images, JSLs, and FSLs
- Supports offline and online resource downloads

Components

- XRocks Printer Controller module
- Included with Base System



